NPN Silicon RF Transistor

- For low noise, low distortion broadband amplifiers in antenna and telecommunications systems up to 1.5GHz at collector currents from 10 mA to 70 mA
- CECC-type available: CECC 50 002/259



ESD: **E**lectro**s**tatic **d**ischarge sensitive device, observe handling precaution!

Type	Marking	Ordering Code	Pin Configuration				Package
BFG 19S	BFG19S	Q62702-F1359	1 = E	2 = B	3 = E	4 = C	SOT-223

Maximum Ratings

Parameter	Symbol	Values	Unit
Collector-emitter voltage	V_{CEO}	15	V
Collector-emitter voltage	V_{CES}	20	
Collector-base voltage	V_{CBO}	20	
Emitter-base voltage	V_{EBO}	3	
Collector current	I_C	100	mA
Base current	I_B	12	
Total power dissipation $T_S \leq 75$ °C	P_{tot}	1	W
Junction temperature	T_j	150	°C
Ambient temperature	T_A	- 65 ... + 150	
Storage temperature	T_{stg}	- 65 ... + 150	
Thermal Resistance			
Junction - soldering point [1)]	R_{thJS}	≤ 75	K/W

1) T_S is measured on the collector lead at the soldering point to the pcb.

Electrical Characteristics at T_A = 25°C, unless otherwise specified.

Parameter	Symbol	Values			Unit
		min.	typ.	max.	
DC Characteristics					
Collector-emitter breakdown voltage I_C = 1 mA, I_B = 0	$V_{(BR)CEO}$	15	-	-	V
Collector-emitter cutoff current V_{CE} = 20 V, V_{BE} = 0	I_{CES}	-	-	100	µA
Collector-base cutoff current V_{CB} = 10 V, I_E = 0	I_{CBO}	-	-	100	nA
Emitter-base cutoff current V_{EB} = 2 V, I_C = 0	I_{EBO}	-	-	10	µA
DC current gain I_C = 70 mA, V_{CE} = 8 V	h_{FE}	40	100	220	-

Electrical Characteristics at T_A = 25°C, unless otherwise specified.

Parameter	Symbol	Values			Unit
		min.	typ.	max.	
AC Characteristics					
Transition frequency I_C = 70 mA, V_{CE} = 8 V, f = 500 MHz	f_T	4	5.5	-	GHz
Collector-base capacitance V_{CB} = 10 V, f = 1 MHz	C_{cb}	-	0.85	1.4	pF
Collector-emitter capacitance V_{CE} = 10 V, f = 1 MHz	C_{ce}	-	0.4	-	
Emitter-base capacitance V_{EB} = 0.5 V, f = 1 MHz	C_{eb}	-	4.6	-	
Noise figure I_C = 20 mA, V_{CE} = 8 V, Z_S = Z_{Sopt} f = 900 MHz f = 1.8 GHz	F	- -	2.5 4	- -	dB
Power gain [2] I_C = 70 mA, V_{CE} = 8 V, Z_S = Z_{Sopt} Z_L = Z_{Lopt} f = 900 MHz f = 1.8 GHz	G_{ma}	- -	13.5 8	- -	
Transducer gain I_C = 30 mA, V_{CE} = 8 V, Z_S =Z_L= 50 Ω f = 900 MHz f = 1.8 GHz	$\lvert S_{21e}\rvert^2$	- -	11 5	- -	
Third order intercept point I_C = 70 mA, V_{CE} = 8 V, f = 900 MHz Z_S =Z_L= 50 Ω	IP_3	-	35	-	dBm

2) $G_{ma} = |S_{21}/S_{12}| (k-(k^2-1)^{1/2})$

Total power dissipation $P_{tot} = f(T_A^*, T_S)$

* Package mounted on epoxy



Permissible Pulse Load $R_{thJS} = f(t_p)$



Permissible Pulse Load $P_{totmax}/P_{totDC} = f(t_p)$



Collector-base capacitance $C_{cb} = f(V_{CB})$
$V_{BE} = v_{be} = 0$, $f = 1$MHz



Transition frequency $f_T = f(I_C)$

V_{CE} = Parameter



Power Gain G_{ma}, $G_{ms} = f(I_C)$
$f = 0.9$GHz
V_{CE} = Parameter



Power Gain G_{ma}, $G_{ms} = f(I_C)$
$f = 1.8$GHz
V_{CE} = Parameter



Power Gain G_{ma}, G_{ms} = $f(V_{CE})$:_____
$|S_{21}|^2$ = $f(V_{CE})$:---------
f = Parameter



Intermodulation Intercept Point IP_3=$f(I_C)$
(3rd order, Output, Z_S=Z_L=50Ω)
V_{CE} = Parameter, f = 900MHz



Power Gain G_{ma}, G_{ms} = $f(f)$

V_{CE} = Parameter



Power Gain $|S_{21}|^2$= $f(f)$

V_{CE} = Parameter



littlediode
COMPONENTS FOR ALL

Littlediode supplies new, hard to find or obsolete electronic components and semiconductors all over the world.

With over two million different components listed you are sure to find the part you need.

Feel free to visit us today at our online store:

LittleDiode.com

Looking forward to providing you with the best possible service.